

Instructions for converting from a Coinco to Mars

Begin by turning the power off to the changer. Remove the Coinco validator and remove the mid (inside) plate. Retain the outside (stainless) plate for re-use with the Mars validator.

It is necessary to slightly modify the existing outside stainless plate. The modification is a slight bevel of the inner upper side of the "slot" opening (in other words... The top of the back side of the outer plate). The outside of the plate will remain as is. This will allow the nose of the Mars mask to fit better in the plate. The best way to make this slight bevel is to use a common file and bench vise. You don't have to be fancy... you are simply "knocking the edge" off of the opening. Test fit the plate to the Mars mask before installing.

To install the Mars validator simply bolt the new inside plate to the modified outside plate and place the Mars over the 4 studs welded in the new inside plate. Do not over tighten. Plug in the harness and restore power.

Please read the info contained in the rest of the instruction set.