

2) The second step is to attach the uprights to the base

- a) obtain the base as shown in the picture to the right
- b) the uprights should look attach as shown in figure 2
- c) next, obtain one (1) 1/4" short bolt and one (1) 1/4" wing nut



1



2



3