

- a) take the side piece marked (This side up (Left)) and place it up against the left side upright as shown in figure 10



10

- b) obtain one (1) 5/16" bolt and place it in the hole as shown in figure 11



11

- c) obtain one (1) 5/16" wingnut and screw it tight onto the bolt as shown in figure 12



12