

d) after tightening the wingnut, it should look like figure 13



13

e) next we need to attach the 45 degree angled part of the side piece. Line up the wood so it looks like figure 14



14

f) attach two (2) 1/4" short bolts in the two holes and attach one (1) of the metal brackets as shown in figure 15



15